





4



5







6 a/b/c*




User Manual

Mounting bracket TERMA RTP 4x


- PL** Instrukcja montażu – mocowanie TERMA RTP
- CS** Pokyny k instalaci – konzole TERMA RTP
- DE** Montageanleitung – Wandhalterung TERMA RTP
- ES** Instrucción de montaje – fijación TERMA RTP
- FR** Instruction du montage – Support de montage TERMA RTP
- IT** Manuale d'uso – staffa di fissaggio TERMA RTP
- NL** Montage instructies – bevestigingsbeugels TERMA RTP
- RU** Инструкция по монтажу – крепление TERMA RTP
- SK** Pokyny k inštalácii – TERMA konzoly RTP



2



3



* **EN** Refers to water and dual fuel version

PL Dotyczy wersji wodnej i wodno-elektrycznej

CS Týká se vodní a hydroelektrické verze.

DE Betrifft die Wasser- und Wasser-Elektrischen Versionen

ES Se refiere a la versión de agua y mixta

FR Concerne la version hydraulique et mixte

IT Si riferisce alla versione idronica e mista.

NL Betreft zowel water- als water/elektrisch verwarmde versies

RU Касается версии водной и водно-электрической

SK Týka sa vodnej a hydroelektrickej verzie.